

Your Global Automation Partner

TURCK

LI-Q25L...E

Linear Position Sensors with Analog Output

Instructions for Use

Contents

- 1 About these instructions 5**
 - 1.1 Target groups 5
 - 1.2 Explanation of symbols used..... 5
 - 1.3 Other documents 5
 - 1.4 Feedback about these instructions 5
- 2 Notes on the product 6**
 - 2.1 Product identification 6
 - 2.2 Scope of delivery..... 6
 - 2.3 Turck service 6
- 3 For your safety 7**
 - 3.1 Intended use 7
 - 3.2 Obvious misuse 7
 - 3.3 General safety notes..... 7
- 4 Product description 8**
 - 4.1 Device overview 8
 - 4.2 Properties and features 9
 - 4.3 Operating principle 9
 - 4.4 Functions and operating modes 9
 - 4.4.1 Output function 9
 - 4.5 Technical accessories 10
 - 4.5.1 Mounting accessories 10
 - 4.5.2 Connection accessories..... 14
- 5 Installing 15**
 - 5.1 Mounting free positioning elements 16
- 6 Connection 17**
 - 6.1 Wiring diagram..... 17
- 7 Commissioning 18**
- 8 Operation..... 19**
 - 8.1 LED indications 19
- 9 Setting 20**
 - 9.1 Setting via manual bridging 20**
 - 9.1.1 Setting the measuring range 20
 - 9.1.2 Reset the sensor to the factory settings..... 20
 - 9.1.3 Reset the sensor to the inverted factory settings..... 20
 - 9.1.4 Activating the teach lock..... 21
 - 9.1.5 Deactivating teach lock..... 21
 - 9.2 Setting via teach adapter 21**
 - 9.2.1 Setting the measuring range 21
 - 9.2.2 Reset the sensor to the factory settings..... 21
 - 9.2.3 Reset the sensor to the inverted factory settings 21
 - 9.2.4 Activating the teach lock..... 22
 - 9.2.5 Deactivating teach lock..... 22
- 10 Troubleshooting..... 23**
- 11 Maintenance 24**

12	Repair	24
12.1	Returning devices	24
13	Disposal.....	24
14	Technical data.....	25
15	Turck subsidiaries — contact information	26

1 About these instructions

These instructions for use describe the structure, functions and the use of the product and will help you to operate the product as intended. Read these instructions carefully before using the product. This is to avoid possible damage to persons, property or the device. Retain the instructions for future use during the service life of the product. If the product is passed on, pass on these instructions as well.

1.1 Target groups

These instructions are aimed at qualified personal and must be carefully read by anyone mounting, commissioning, operating, maintaining, dismantling or disposing of the device.

1.2 Explanation of symbols used

The following symbols are used in these instructions:



DANGER

DANGER indicates a dangerous situation with high risk of death or severe injury if not avoided.



WARNING

WARNING indicates a dangerous situation with medium risk of death or severe injury if not avoided.



CAUTION

CAUTION indicates a dangerous situation of medium risk which may result in minor or moderate injury if not avoided.



NOTICE

NOTICE indicates a situation which may lead to property damage if not avoided.



NOTE

NOTE indicates tips, recommendations and useful information on specific actions and facts. The notes simplify your work and help you to avoid additional work.



CALL TO ACTION

This symbol denotes actions that the user must carry out.



RESULTS OF ACTION

This symbol denotes relevant results of actions.

1.3 Other documents

Besides this document, the following material can be found on the Internet at www.turck.com:

- Data sheet



1.4 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to techdoc@turck.com.

2 Notes on the product

2.1 Product identification

LI 100 P1 Q25L M1 E LIU5 X3 H1151



2.2 Scope of delivery

The scope of delivery includes:

- Linear position sensor (without positioning element)
- Optional: Positioning element and mounting element

2.3 Turck service

Turck supports you with your projects, from initial analysis to the commissioning of your application. The Turck product database under www.turck.com contains software tools for programming, configuration or commissioning, data sheets and CAD files in numerous export formats.

The contact details of Turck subsidiaries worldwide can be found on p. [▶ 26].

3 For your safety

The product is designed according to state-of-the-art technology. However, residual risks still exist. Observe the following warnings and safety notices to prevent damage to persons and property. Turck accepts no liability for damage caused by failure to observe these warning and safety notices.

3.1 Intended use

The inductive linear position sensors are used for contactless and wear-free linear position measuring.

The devices may only be used as described in these instructions. Any other use is not in accordance with the intended use. Turck accepts no liability for any resulting damage.

3.2 Obvious misuse

- The devices are not safety components and must not be used for personal or property protection.

3.3 General safety notes

- The device may only be assembled, installed, operated, parameterized and maintained by professionally-trained personnel.
- The device may only be used in accordance with applicable national and international regulations, standards and laws.
- The device meets the EMC requirements for industrial areas. When used in residential areas, take measures to avoid radio interference.

4 Product description

The inductive linear position sensors of the Li-Q25L product series consist of a sensor and a positioning element. The two components form a measuring system for measuring for converting the measured variable, length or position.

The sensors are supplied with a measuring length of 100...2000 mm: In the 100...1000-mm range, variants are available in 100-mm increments, in the 1000...2000-mm range in 250-mm increments. The maximum measuring range of the sensor is determined by its length. However, the start point of the measuring range can be individually adapted using a teach-in process.

The sensor is housed in a rectangular aluminum profile. The positioning element is available in different variants in a plastic housing (cf. accessories list in chapter 4.5). The sensor and positioning element fulfill the requirements of protection class IP67 and can withstand vibrations of moving machine parts as well as a range of other aggressive ambient conditions for long periods of time. The sensor and positioning element together enable contactless and wear-free measuring. The sensors operate in absolute mode. Power outages do not require renewed zero offset adjustment or recalibration. All position values are determined as absolute values. Homing movements after a voltage drop are unnecessary.

4.1 Device overview




Fig. 1: Dimensions in mm – $L = 29 \text{ mm} + \text{measuring length} + 29 \text{ mm}$




Fig. 2: Dimensions – device height

4.2 Properties and features

- Measurement lengths from 100...2000 mm
- Shock-proof up to 200 g
- Maintains linearity under shock load
- Immune to electromagnetic interference
- 5-kHz sampling rate
- 16-bit resolution

4.3 Operating principle

The Li-Q25L linear position sensors have contactless operation based on the inductive resonant circuit measuring principle. Measuring is immune to magnetic fields as the positioning element is not based on a magnet but on a coil system. Sensor and positioning element form an inductive measuring system. An induced voltage generates appropriate signals in the receiver coils of the sensor, depending on the location of the positioning element. The signals are evaluated in the internal 16-bit processor of the sensor and output as analog signals.

4.4 Functions and operating modes

The devices feature a current and voltage output. The device provides a current and voltage signal at the output proportional to the position of the positioning element.




Fig. 3: Output characteristics

4.4.1 Output function

The measuring range of the sensor starts at 4 mA or 0 V and ends at 20 mA or 10 V. Current and voltage output can be used simultaneously. Current and voltage outputs can be used simultaneously for functions such as redundant signal evaluation. In addition, one display unit can receive a signal while the second signal is processed by a PLC.


In addition to the LEDs, the sensor offers an additional control function. If the positioning element is outside the detection range and the coupling between the sensor and the positioning element is interrupted, the analog output of the sensor outputs 24 mA or 11 V as a fault signal. This error can therefore be evaluated directly via the higher-level control.

4.5 Technical accessories

4.5.1 Mounting accessories

Dimension drawing	Type	ID	Description
	P1-LI-Q25L	6901041	Guided positioning element for LI-Q25L linear position sensors, inserted in the groove of the sensor
	P2-LI-Q25L	6901042	Floating positioning element for LI-Q25L linear position sensors; the nominal distance to the sensor is 1.5 mm; pairing with the linear position sensor at a distance of up to 5 mm or a misalignment tolerance of up to 4 mm
	P3-LI-Q25L	6901044	Floating positioning element for LI-Q25L linear position sensors; operational at an offset of 90°; the nominal distance to the sensor is 1.5 mm; pairing with the linear position sensor at a distance of up to 5 mm or a misalignment tolerance of up to 4 mm

Dimension drawing



Type

P6-LI-Q25L

ID

6901069


Description

Floating positioning element for LI-Q25L linear position sensors; the nominal distance to the sensor is 1.5 mm; pairing with the linear position sensor at a distance of up to 5 mm or a misalignment tolerance of up to 4 mm

Type

P7-LI-Q25L 6901087


Guided positioning element for LI- Q25L linear position sensors, without ball joint





Type


M1-Q25L 6901045


Mounting foot for LI-Q25L linear position sensors; material: aluminum; 2 pcs. per bag





Dimension drawing	Type	ID	Description
	M2-Q25L	6901046	Mounting foot for LI-Q25L linear position sensors; material: aluminum; 2 pcs. per bag




	M4-Q25L	6901048	Mounting bracket and sliding block for LI-Q25L linear position sensors; material: stainless steel; 2 pcs. per bag
------------------------------------------------------------------------------------	---------	---------	-------------------------------------------------------------------------------------------------------------------




	MN-M4-Q25	6901025	Sliding block with M4 thread for the backside profile of the LI-Q25L linear position sensor; material: galvanized metal; 10 pcs. per bag
-------------------------------------------------------------------------------------	-----------	---------	------------------------------------------------------------------------------------------------------------------------------------------




Dimension drawing	Type	ID	Description
	AB-M5	6901057	Axial joint for guided positioning element



	ABVA-M5	6901058	Axial joint for guided positioning elements; material: stainless steel
--	---------	---------	------------------------------------------------------------------------



	RBVA-M5	6901059	Angle joint for guided positioning element; material: stainless steel
--	---------	---------	-----------------------------------------------------------------------



4.5.2 Connection accessories

Dimension drawing	Type	ID	Description
	TX1-Q20L60	6967114	Teach adapter
	RKS4.5T-2/ TXL	6626373	Connection cable, M12 female connector, straight, 5-pin, shielded: 2 m, jacket material: PUR, black; cULus approval; other cable lengths and versions available, see www.turck.com

5 Installing



NOTE

Install positioning elements centrally above the sensor. Observe LED behavior (see chapter "Operation").

- ▶ Install the linear position sensor in the system using the required mounting accessories.





Fig. 4: Example — installation with mounting foot or mounting bracket

Mounting element	Recommended tightening torque
M1-Q25L	3 Nm
M2-Q25L	3 Nm
MN-M4-Q25L	2.2 Nm

Sensor type	Recommended number of fixings
LI100...LI500	2
LI600...LI1000	4
LI1250...LI1500	6
LI1750...LI2000	8

5.1 Mounting free positioning elements

- ▶ Center the free positioning element above the sensor.
- ▶ If LED 1 lights up yellow, the positioning element is in the measuring range. Signal quality is degraded. Correct the alignment of the positioning element until LED 1 lights up green.
- ▶ If LED 1 flashes yellow, the positioning element is not in the measuring range. Correct the alignment of the positioning element until LED 1 lights up green.
- ⇒ LED 1 lights up green when the positioning element is in the measuring range.




Fig. 5: Center the free positioning element

6 Connection



NOTICE

Incorrect female connector

Damage to the M12 male connector possible

- ▶ Ensure correct connection.



NOTE

Turck recommends the use of shielded connection cables.

- ▶ During the electrical installation of the sensor, keep the entire system de-energized.
- ▶ Connect the female connector of the connection cable to the male connector of the sensor.
- ▶ Connect the open end of the connection cable to the power supply and/or processing units.

6.1 Wiring diagram



NOTE

To prevent unintentional teaching, keep pin 5 potential-free or activate the teach lock.





Fig. 6: M12 male connector — pin assignment Fig. 7: M12 male connector — wiring diagram

7 Commissioning

After connecting and switching on the power supply, the device is automatically ready for operation.

8 Operation

8.1 LED indications




Fig. 8: LEDs 1 and 2

LED	Display	Meaning
LED 1	Green	Positioning element within the measuring range
	Yellow	Positioning element within the measuring range with a reduced signal quality (e.g. distance to sensor too large)
	Yellow flashing	Positioning element not in detection range
	Off	Positioning element outside the set measuring range
LED 2	Green	Power supply error-free

9 Setting

The sensor offers the following setting options:

- Set the start of the measuring range (zero point)
- Set the end of the measuring range (end point)
- Reset measuring range to factory setting: largest possible measuring range
- Reset measuring range to inverted factory setting: largest possible measuring range, output curve inverted
- Activate/deactivate teach lock

The measuring range can be set by manual bridging or with the TX1-Q20L60 teach adapter. The zero point and end point of the measuring range can be set in succession or separately.



NOTE

To prevent unintentional teaching, keep pin 5 potential-free or activate the teach lock.

9.1 Setting via manual bridging

9.1.1 Setting the measuring range

- ▶ Supply the device with voltage.
- ▶ Place the positioning element at the desired zero point of the measuring range.
- ▶ Bridge pin 5 and pin 3 for 2 s.
- ⇒ LED 2 flashes green for 2 s during bridging.
- ⇒ The zero point of the measuring range is stored.
- ▶ Supply the device with voltage.
- ▶ Place the positioning element at the desired end point of the measuring range.
- ▶ Bridge pin 5 and pin 1 for 2 s.
- ⇒ LED 2 flashes green for 2 s during bridging.
- ⇒ The end point of the measuring range is stored.

9.1.2 Reset the sensor to the factory settings

- ▶ Supply the device with voltage.
- ▶ Bridge pin 5 and pin 1 for 10 s.
- ⇒ LED 2 initially flashes green for 2 s, then lights up green continuously for 8 s and flashes green again (after a total of 10 s).
- ⇒ The sensor is reset to its factory setting.

9.1.3 Reset the sensor to the inverted factory settings

- ▶ Supply the device with voltage.
- ▶ Bridge pin 5 and pin 3 for 10 s.
- ⇒ LED 2 initially flashes green for 2 s, then lights up green continuously for 8 s and flashes green again (after a total of 10 s).
- ⇒ The sensor is reset to its inverted factory setting.

9.1.4 Activating the teach lock



NOTE

The teach lock function is deactivated on delivery.

- ▶ Supply the device with voltage.
- ▶ Bridge pin 5 and pin 1 for 30 s.
- ⇒ LED 2 initially flashes green for 2 s, then lights up green continuously for 8 s, flashes green again (after a total of 10 s) and flashes green (after a total of 30 s) at a higher frequency.
- ⇒ The teach lock function of the sensor is activated.

9.1.5 Deactivating teach lock

- ▶ Supply the device with voltage.
- ▶ Bridge pin 5 and pin 1 for 30 s.
- ⇒ LED 2 lights up green continuously for 30 s (teach lock is still activated) and after 30 s flashes green at a higher frequency.
- ⇒ The teach lock function of the sensor is deactivated.

9.2 Setting via teach adapter

9.2.1 Setting the measuring range

- ▶ Supply the device with voltage.
- ▶ Place the positioning element at the zero point of the measuring range.
- ▶ Teach-in the pushbutton on the adapter for 2 s against GND.
- ⇒ LED 2 flashes green for 2 s and then lights up green continuously.
- ⇒ The zero point of the measuring range is stored.
- ▶ Supply the device with voltage.
- ▶ Place the positioning element at the end point of the measuring range.
- ▶ Teach-in the pushbutton on the adapter for 2 s against U_B .
- ⇒ LED 2 flashes green for 2 s and then lights up green continuously.
- ⇒ The zero point of the measuring range is stored.

9.2.2 Reset the sensor to the factory settings

- ▶ Supply the device with voltage.
- ▶ Teach-in the pushbutton on the adapter for 10 s against U_B .
- ⇒ LED 2 initially flashes green for 2 s, then lights up green continuously for 8 s and flashes green again (after a total of 10 s).
- ⇒ The sensor is reset to the factory setting.

9.2.3 Reset the sensor to the inverted factory settings

- ▶ Supply the device with voltage.
- ▶ Teach-in the pushbutton on the adapter for 10 s against GND.
- ⇒ LED 2 initially flashes green for 2 s, then lights up green continuously for 8 s and flashes green again (after a total of 10 s).
- ⇒ The sensor is reset to the inverted factory setting.

9.2.4 Activating the teach lock



NOTE

The teach lock function is deactivated on delivery.

- ▶ Supply the device with voltage.
- ▶ Teach-in the pushbutton on the adapter for 30 s against U_B .
- ⇒ LED 2 initially flashes green for 2 s, then lights up green continuously for 8 s, flashes green again (after a total of 10 s) and flashes green (after a total of 30 s) at a higher frequency.
- ⇒ The teach lock function of the sensor is activated.

9.2.5 Deactivating teach lock

- ▶ Supply the device with voltage.
- ▶ Teach-in the pushbutton on the adapter for 30 s against U_B .
- ⇒ LED 2 lights up green continuously for 30 s (teach lock is still activated) and after 30 s flashes green at a higher frequency.
- ⇒ The teach lock function of the sensor is deactivated.

10 Troubleshooting

The strength of the resonance coupling is indicated by an LED. Any faults are indicated via the LEDs.

If the device does not function as expected, first check whether ambient interference is present. If there is no ambient interference present, check the connections of the device for faults.

If there are no faults, there is a device malfunction. In this case, decommission the device and replace it with a new device of the same type.

11 Maintenance

Ensure that the plug connections and cables are always in good condition.

The devices are maintenance-free, clean dry if required.

12 Repair

The device must not be repaired by the user. The device must be decommissioned if it is faulty. Observe our return acceptance conditions when returning the device to Turck.

12.1 Returning devices

Returns to Turck can only be accepted if the device has been equipped with a Decontamination declaration enclosed. The decontamination declaration can be downloaded from <https://www.turck.de/en/retoure-service-6079.php> and must be completely filled in, and affixed securely and weather-proof to the outside of the packaging.

13 Disposal



The devices must be disposed of correctly and must not be included in general household garbage.

14 Technical data

Technical data	
Measuring range specifications	
Measuring range	100...1000 mm in 100-mm increments; 1250...2000 mm in 250-mm increments
Resolution	16 bit
Nominal distance	1.5 mm
Blind zone a	29 mm
Blind zone b	29 mm
Repetition accuracy	≤ 0.02 % of full scale
Linearity tolerance	Depending on the measuring length (see data sheet)
Temperature drift	≤ ± 0.003 %/K
Hysteresis	Omitted as a matter of principle
Ambient temperature	-25...+70 °C
Operating voltage	15... 30 VDC
Ripple	≤ 10 % U _{ss}
Insulation test voltage	≤ 0.5 kV
Short-circuit protection	Yes
Wire breakage/reverse polarity protection	Yes/yes (power supply)
Output function	5-pin, analog output
Voltage output	0...10 V
Current output	4...20 mA
Load resistance, voltage output	≥ 4.7 kΩ
Load resistance, current output	≤ 0.4 kΩ
Sampling rate	5 kHz
Current consumption	< 50 mA
Design	Rectangular, Q25L
Dimensions	(Measurement length + 58) × 35 × 25 mm
Housing material	Anodized aluminum
Material of active face	Plastic, PA6-GF30
Electrical connection	Male connector, M12 × 1
Vibration resistance (EN 60068-2-6)	20 g; 1.25 h/axis; 3 axes
Shock resistance (EN 60068-2-27)	200 g; 4 ms ½ sine
Type of protection	IP67/IP66
MTTF	138 years acc. to SN 29500 (Ed. 99) 40 °C
Packed quantity	1
Operating voltage indication	LED: green
Measuring range display	Multifunction LED: green, yellow, yellow flashing

15 Turck subsidiaries — contact information

Germany	Hans Turck GmbH & Co. KG Witzlebenstraße 7, 45472 Mülheim an der Ruhr www.turck.de
Australia	Turck Australia Pty Ltd Building 4, 19-25 Duerdin Street, Notting Hill, 3168 Victoria www.turck.com.au
Belgium	TURCK MULTIPROX Lion d'Orweg 12, B-9300 Aalst www.multiprox.be
Brazil	Turck do Brasil Automação Ltda. Rua Anjo Custódio Nr. 42, Jardim Anália Franco, CEP 03358-040 São Paulo www.turck.com.br
China	Turck (Tianjin) Sensor Co. Ltd. 18,4th Xinghuazhi Road, Xiqing Economic Development Area, 300381 Tianjin www.turck.com.cn
France	TURCK BANNER S.A.S. 11 rue de Courtalin Bat C, Magny Le Hongre, F-77703 MARNE LA VALLEE Cedex 4 www.turckbanner.fr
Great Britain	TURCK BANNER LIMITED Blenheim House, Hurricane Way, GB-SS11 8YT Wickford, Essex www.turckbanner.co.uk
India	TURCK India Automation Pvt. Ltd. 401-403 Aurum Avenue, Survey. No 109 /4, Near Cummins Complex, Baner-Balewadi Link Rd., 411045 Pune - Maharashtra www.turck.co.in
Italy	TURCK BANNER S.R.L. Via San Domenico 5, IT-20008 Bareggio (MI) www.turckbanner.it
Japan	TURCK Japan Corporation Syuuhou Bldg. 6F, 2-13-12, Kanda-Sudacho, Chiyoda-ku, 101-0041 Tokyo www.turck.jp
Canada	Turck Canada Inc. 140 Duffield Drive, CDN-Markham, Ontario L6G 1B5 www.turck.ca
Korea	Turck Korea Co, Ltd. B-509 Gwangmyeong Technopark, 60 Haan-ro, Gwangmyeong-si, 14322 Gyeonggi-Do www.turck.kr
Malaysia	Turck Banner Malaysia Sdn Bhd Unit A-23A-08, Tower A, Pinnacle Petaling Jaya, Jalan Utara C, 46200 Petaling Jaya Selangor www.turckbanner.my

Mexico	Turck Comercial, S. de RL de CV Blvd. Campestre No. 100, Parque Industrial SERVER, C.P. 25350 Arteaga, Coahuila www.turck.com.mx
Netherlands	Turck B. V. Ruiterlaan 7, NL-8019 BN Zwolle www.turck.nl
Austria	Turck GmbH Graumanngasse 7/A5-1, A-1150 Wien www.turck.at
Poland	TURCK sp.z.o.o. Wroclawska 115, PL-45-836 Opole www.turck.pl
Romania	Turck Automation Romania SRL Str. Siriului nr. 6-8, Sector 1, RO-014354 Bucuresti www.turck.ro
Russian Federation	TURCK RUS OOO 2-nd Pryadilnaya Street, 1, 105037 Moscow www.turck.ru
Sweden	Turck Sweden Office Fabriksstråket 9, 433 76 Jonsered www.turck.se
Singapore	TURCK BANNER Singapore Pte. Ltd. 25 International Business Park, #04-75/77 (West Wing) German Centre, 609916 Singapore www.turckbanner.sg
South Africa	Turck Banner (Pty) Ltd Boeing Road East, Bedfordview, ZA-2007 Johannesburg www.turckbanner.co.za
Czech Republic	TURCK s.r.o. Na Brne 2065, CZ-500 06 Hradec Králové www.turck.cz
Turkey	Turck Otomasyon Ticaret Limited Sirketi Inönü mah. Kayisdagi c., Yesil Konak Evleri No: 178, A Blok D:4, 34755 Kadiköy/ Istanbul www.turck.com.tr
Hungary	TURCK Hungary kft. Árpád fejedelem útja 26-28., Óbuda Gate, 2. em., H-1023 Budapest www.turck.hu
USA	Turck Inc. 3000 Campus Drive, USA-MN 55441 Minneapolis www.turck.us

TURCK

Over 30 subsidiaries and
60 representations worldwide!

100003779 | 2022/08



www.turck.com